

Prospecting for Lunar Water-Ice Using Infrared Reflectance Spectroscopy of the Moon's Surface

Using remotely sensed grain size of surficial water to infer origin as either frost or exposed subsurface ice


C. A. Hibbitts, C. Wagoner, A. Takeuchi, L. Pascale

JHU-APL, 11100 Johns Hopkins Rd., Laurel, Md., 20723, karl.hibbitts@jhuapl.edu


Research supported by NASA SSW Grant: 80NSSC21K0171 & SSERVI Grant CLEVER

Ice in PSRs and discrimination by grain size

Water-ice albedo models




Frost is finer-grained than all



Spectral Detection of Ice in Permanently Shadowed Regions (PSRs)



- PSRs can be $\ll 110\text{K}$. The colder they are, the darker they are.
- They have variable levels of illumination, but still enough
 - Reflected light from illuminated terrain
 - Emitted thermal light from illuminated terrain
 - Earthshine
- Infrared Reflectance spectroscopy possible

KPLO ShadowCam images
of shadowed Shackleton
Crater (ASU)



LROC NASA/ASU

Illumination in Permanently Shadowed Regions (PSRs)



CRONOS facility — Cryogenic Reflectance Observations using Nitrogen-purged Optical Spectroscopy


400 – 2400 nm cryogenic reflectance on powders of lunar simulants and sieved ice

Sample Preparation



Grinding & wet sieving ice (and anorthite and ice mixtures) w/ liquid nitrogen in an N₂-purged box.

Cryogenic Reflectance




From Berdis, 2025 (this LPSC)

Subsequently, taking cryogenic 1 – 2.5 μm reflectance spectra w/ liquid nitrogen in same N₂-purged box.


CRONOS facility — Cryogenic Reflectance Observations using Nitrogen-purged Optical Spectroscopy

- The 1.5 and 2-micron bands grow proportionally with increasing ice abundance. $\Delta 1.5/\Delta 2=0.58$
- Trend is independent of fractional abundance of ice, mixture style, and grain size (at these low abundances)

Spectra of Frost on LHS-1 @ 180K





Band Depths of Frost & of Ice Mixed with LHS-1 or LMS-1






LabSPEC Laboratory for Spectroscopy under Planetary Environmental Conditions

- Cryogenic Reflectance Spectroscopy:
 - SVC: 400 – 2400 nm
 - Bruker V70 FTIR: ~ 1300 – 7500 nm
- Laser Irradiation:
 - 1064-nm, 400 mJ, 5.25 ns pulse, ~1 mm beam diameter



Pure Ice (not realistic)


Spectra of Ice before and after disruption by lasing to simulate the physical disruption of micrometeoroid bombardment



(A) Massive ice; (B) Laser irradiated; (C) Frost on massive ice; (D) Frost only



Comminuted Ice Deposit: Granular Mixtures of Water Ice and Highland Simulant

LHS highland simulant with 10% water-ice w/w 63 – 250 micron





Comminuted Ice Deposit: Granular Mixtures of Water Ice and Highland Simulant

LHS highland simulant with 10% water-ice w/w 63 – 250 micron



Comminuted Ice Deposit: Granular Mixtures of Water Ice and Highland Simulant


LHS highland simulant with 10% water-ice w/w 63 – 250 micron




Comminuted Ice Deposit: Granular Mixtures of Water Ice and Highland Simulant

LHS highland simulant with 10% water-ice w/w 63 – 250 micron

After exposing desiccated sample to atmosphere briefly to form frost




- Frost has relatively large 3-micron band
- The 6-micron band is insensitive to ice
- The 1.5 and 2-micron bands grow proportionally with increasing ice abundance $\Delta 1.5/\Delta 2=0.59$



Comminuted Ice Deposit 2: Granular Mixtures of Water Ice and Highland Simulant


LHS highland simulant with 10% water-ice w/w 250 – 500 micron




Begins with a desiccated surface
Ice is exposed by lasing
Frost adds to and shifts the 3-um band but doesn't affect the 1.5 and 2-um bands

What does frost on desiccated simulant look like?



Massive Ice Deposit: Frozen Slurry of Water and Highland Simulant



Massive Ice Deposit: Frozen Slurry of Water and Highland Simulant



Vacuum Chamber: Mixtures of Water and Highland Simulant (frozen)




Conclusions


in the infrared spectral characteristic of water-ice at <10% abundances

1. The depths of the 1.5- and 2-micron bands vary linearly with a $\Delta 1.5/\Delta 2$ of ~ 0.6 independent of grain size, albedo of material it is mixed with (at least to some extent), mixing style (so far), and abundance.
 - Not likely possible to only use the SWIR to constrain both grain size and abundance. One has to be known
 - A ~ 2 -micron band only is not necessarily indicative of water ice; it is also present with adsorbed water
2. Including the 3-micron band is enabling to discerning ice grain size at low ice abundance.
 - Surface frost can potentially be distinguished from ice intimately mixed with regolith by a relatively deep 3-micron band compared to the 2-micron band.
 - Thus, it may be possible to discern excavated ice (larger grained) from surface frost
3. The 6-micron band is uniquely capable of detecting molecular H_2O in forms other than ice; water ice does not contribute to the 6-micron absorption.
4. Recommendation:
 - Orbital and rover missions would need to leverage both the 2- and 3-micron bands to understand grain size to infer origin and evolution of low abundances of ice on the Moon or other non-icy surfaces. The 1.5-micron band can be too weak at low ice abundances and the 6-micron band is not sensitive to ice.


Extra



Water Ice Sieve Fractions



Albedo models



Laboratory bidirectional reflectance ($i=15^\circ$, $e=45^\circ$)

